

ASSEMBLY INSTRUCTIONS




THIS ARTICLE REQUIRES ASSEMBLY


THE BOX INCLUDES

- (1) Shade Fixture (A)
- (2) Lamp Stand (B)
- (3) Top Nut (C)





- (1) Unscrew the top nut (C) from the head of the lamp stand (B).
- (2) Carefully place the shade (A) over the lamp stand (B) insure that it is aligned so that the top nut (C) can be re-screwed.
- (3) Slightly move the shade to check if it has been adequately tightened. If it feels loose screw in the top nut (C) until it is tightly screwed.
- (4) The lamp is ready to use.



To prevent the risk of fire, do not use light bulb with wattage greater than 40W.

* IF THE EXTERNAL FLEXIBLE CABLE OR CORD OF THIS TABLE LAMP NEEDS TO BE CHANGED IT SHOULD ONLY BE REPLACED BY A QUALIFIED ELECTRICIAN